


SwiGO Smart and Self-Starter Connection for Single Phase Submersible Starters

Connect Yellow wires to the one pole of Green Start Button


Connect Blue wires to another pole of Green Start Button

Connect Phase and Neutral wires from SwiGO Smart L&N OUT to your Starters' P&N

To Submersible Pump



Optionally connect float switch if your tank gets full occasionally before time elapses



N
L

P
N